



## Painting Interior Walls, Doors and Trim

### General preparation

All loose material must be removed and surface damage or imperfections made good.

The surface must be clean, dry and free of contaminants.

Areas with a build up of grime must be cleaned with sugar soap.

Remove mould or mildew with a dilute bleach treatment and rinse clean.

Surface	Prep and repair	Prime/seal	General wall finish	Doors, trim, high traffic areas	Wet areas: bathrooms, laundries finish
Previously painted enamel and polyurethane	Sand thoroughly with sand paper to completely remove gloss and clean with a lint free cloth. Spot prime repairs and bare areas.	Easy Sand	Apply 2 coats of Easy Flow	Apply 2 coats of ArmourGuard® Satin or Semi - Gloss	Apply 2 coats of ArmourGuard® Low Sheen or Satin
Previously painted acrylic	Lightly sand with sand paper (P240) to denib and dust with a Wooster Dust Eater or similar. Stopping repairs – spot prime with PaintPlus Easy sand or Quick Prep.	Easy Sand	Apply 2 coats of Easy Flow	Apply 2 coats of ArmourGuard® Satin or Semi - Gloss	Apply 2 coats of ArmourGuard® Low Sheen or Satin
New paper faced wall board, Gib® -dead flat finish	Seal, sand and clean with a lint free cloth.	Easy Sand	Apply 2 coats of Easy Flow	Apply 2 coats of ArmourGuard® Satin or Semi - Gloss	Apply 2 coats of ArmourGuard® Low Sheen or Satin
Lathe and plaster	Rake repairs, fill and fibre fuse tape and plaster entire wall.	Easy Sand	Apply 2 coats of Easy Flow	Apply 2 coats of ArmourGuard® Satin or Semi - Gloss	Apply 2 coats of ArmourGuard® Low Sheen or Satin
Vinyl wall paper	Clean with sugar soap and prime.	Quick Prep	Apply 2 coats of Easy Flow	Apply 2 coats of ArmourGuard® Satin or Semi - Gloss	Apply 2 coats of ArmourGuard® Low Sheen or Satin
Timber linings, MDF	Seal, lightly sand to de-nib and clean with a lint free cloth.	Quick Prep	Apply 2 coats of Easy Flow	Apply 2 coats of ArmourGuard® Satin or Semi - Gloss	Apply 2 coats of ArmourGuard® Low Sheen or Satin

### Tools and spread rates

Product	Sheen	Spread rate SqM/l per coat	Recommended roller sleeve	Recommended airless tip size
Easy Sand Acrylic Sealer Undercoat	N/A	6–10	Wooster Pro-Dooz 14 -16mm	Airless tip size 517–519
Quick Prep General Purpose Undercoat	N/A	10–12	Wooster Pro-Dooz 14 -16mm	Airless tip size 517–519
Easy Flow Interior Low Sheen	7%	10–14	Wooster Pro-Dooz 14 -16mm	Airless tip size 517–519
ArmourGuard® Low Sheen Interior Water based Enamel	7%	12–14	Wooster ProDooz 10mm Wooster Microplush 7mm	Airless tip size 511
ArmourGuard® Satin Interior Water based Enamel	15%	12–14	Wooster ProDooz 10mm Wooster Microplush 7mm	Airless tip size 511
ArmourGuard® Semi-Gloss Interior Water based Enamel	30%	12–14	Wooster ProDooz 10mm Wooster Microplush 7mm	Airless tip size 511
Brush choice	A Wooster Silver Tip brush is recommended for ArmourGuard® and Wooster Ultra Pro brush for other products.			

**Notes/limitations:** Airless spray applications where a very high level of finish is required – double coat with PaintPlus Easy Sand.